

Spreader arm wire attachment positions  
KIO Hexagonal beam

**Clamp/P clip positions on spreaders are initial positions subject to adjustment when wires are installed, for optimal tension/slack.**

