


Wire Guide Locations on 48 inch* Spreader Arms


January 2026




*Replacement spreader arm sections purchased individually from Max Gain Systems are 46.5 inches long instead of the standard 48 inches. So to compensate for this, the 4 inches telescoped lengths of the medium and small spreader sections should be reduced to 2.5 inches. This increases the splitting force on the ends of the large and the medium spreader sections and this splitting force can be offset by use of a clamp on the end as well as the stop clamp.

Wire Guide Locations on 46 1/2 inch Spreader Arms



January 2026



#6 Stop clamp



Wire guide



Distances from left end